

**LINE BANDING**

1. Select BAND option.
  2. Place tip of Pen at point where BANDING is to start. Press SPACE BAR.
  3. To 'PIN POINT' use CURSOR keys.
  4. Repeat 2 & 3 at points where lines are required to run.
- To quit this option press ESC key.

**FILL**

1. Select FILL option.
  2. Select FILL colour.
  3. Point pen at position within an enclosed area which you wish to FILL.
  4. Press SPACE BAR.
  5. To 'PIN POINT' use CURSOR keys.
  6. Press SPACE BAR.
- To quit this option press ESC key.

**COLOUR**

1. Select COLR option.
2. Select colour on menu.

**EXIT**

Select EXIT to leave program.

**NEW**

1. Select NEW option.
2. Press Y to clear screen.

**BRILLIANCE**

Point Pen at Box to the right of BRI. The number will change from 0 through to 7. The higher the number selected the brighter the option will be drawn.

**BACKGROUND COLOUR**

Select this option to draw options in BACKGROUND colour. Use COLOUR option to change BACKGROUND colour.

**PENS 1, 2 & 3**

Use this option as shown in PLUS 4 section.

**SCREEN DUMP TO PRINTER**

1. Select EXIT in MAIN Menu.