

2. Point pen at point on screen where you wish BANDING to start.
3. Press CONTROL key. Screen will flash and point will appear on the screen.
4. You may now 'PIN POINT' the 1st cursor by use of the CURSOR keys.

Repeat Nos.2, 3 & 4 above as often as required to BAND lines.

RAYS

1. Select RAYS option.
2. Point pen at point on screen where you wish centre of RAY to be positioned.
3. Press CONTROL key. Screen will flash and point will appear on the screen.
4. You may now 'PIN POINT' the 1st cursor by use of the CURSOR keys.

Repeat Nos.2 to 4 in different positions to produce a RAY.

This option can be used as often as required.

To quit this option press the SPACE BAR.

LINE

1. Select LINE option.
2. Point pen at point on screen where you wish one end of the LINE to appear.
3. Press CONTROL key. Screen will flash and point will appear on the screen.
4. You may now 'PIN POINT' the 1st cursor by use of the CURSOR keys.

Repeat Nos.2, 3 & 4 for other end of line.

This option may be repeated as often as required.

To quit this option press SPACE BAR.

TRIANGLE

1. Select TRIANGLE option.
2. Point pen at point on screen where you wish the first corner of the TRIANGLE to appear on the screen.
3. Press CONTROL key. Screen will flash and point will appear on the screen.
4. You may now 'PIN POINT' the 1st cursor by use of the CURSOR keys.

Repeat Nos.2, 3 & 4 for each of the other two corners of the TRIANGLE.

To quit this option press SPACE BAR.